

Operating and mounting manual control valve flow-control-slide-valve MRS Ro We/St/Pn

Contents

- 1.0 General Remarks**
 - 1.1 Valve data
 - 1.2 Application
- 2.0 Danger Notices**
 - 2.1 Safety terms
 - 2.2 Safety notice
 - 2.3 Qualified staff
 - 2.4 Unauthorized modification and spare part production
 - 2.5 Unauthorized operation
 - 2.6 Safety information for the use in explosion-prone areas guideline 2014/34/EU
 - 2.7 Safety information regarding guideline 2014/68/EU attachment I
- 3.0 Handling**
 - 3.1 Transport
 - 3.2 Storage
 - 3.3 Handling before mounting
- 4.0 Product Description**
 - 4.1 Function
 - 4.2 Technical data
 - 4.3 Marking
 - 4.4 Selection of electric actuators and pneumatic rotary actuators
- 5.0 Installation**
 - 5.1 Warning of dangers during installation, operation and maintenance
 - 5.2 Installation
- 6.0 Operation**
 - 6.1 Commissioning
 - 6.2 Shutting down
 - 6.3 Maintenance
 - 6.4 Putting back into operating
- 7.0 Troubleshooting**
 - 7.1 Detection of defects
 - 7.2 Troubleshooting plan
- 8.0 Replace the flow-control-slide-valves**
 - 8.1 Replacement of wear parts
- 9.0 Warranty**
- 10.0 Explanations on Codes and Directives**
- 11.0 Drawing**
 - 11.1 Sectional drawing
 - 11.2 View drawing
 - 11.3 List of parts
 - 11.4 Dimension

1.0 General Remarks

This operating manual includes instructions to assemble and operate the flow-control-slide-valves in the prescribed and safe way.

If any difficulties appear that can not be solved by means of the operation instructions, further information may be demanded from the manufacturer. This operating manual is in accordance with the relevant valid EN safety standards and the valid prescriptions and rules of the Federal Republic of Germany.

If the flow-control-slide-valves are used abroad of the FRG, the operator and/or the person who is responsible for the plant concept must take care that the valid national rules are met.

The manufacturer reserves the right of any technical change and improvement.

The use of these operating instructions assumes the qualification of the user according to paragraph 2.3 "qualified staff". The operating staff must be trained in accordance with the operating instructions. The operating manual must always be available at the location where used.

1.1 Valve data

Manufacturer:

UNI Geräte E. Mangelmann
Elektrotechnische Fabrik GmbH
Holtumsweg 13
D-47652 Weeze
Telefon: +49 (0) 2837/9134-0
Fax: +49 (0) 2837/1444
E-Mail: info@uni-geraete.de
Homepage: www.uni-geraete.de

Designation

Control valve as actuator for controlling without zero closure

Type of drive:	We	with free shaft end
Working pressure:	10-MRS Ro We ...	0 – 10bar
Type of drive:	St	with electrical actuator
Working pressure:	10-MRS Ro St ...	0 – 10bar
Type of drive:	Pn	with pneumatic actuator
Working pressure:	10-MRS Ro Pn ...	0 – 10bar
Medium and Ambient temperature:	-20°C to + 60°C	
Fitting position:	We	arbitrary
	St/Pn	vertical or horizontal drive

Optional with drive type We: Hand adjuster (Ha)
Hand lever with scale

Flange connection measures DN15 – DN50 acc. to DIN EN 1092-2 / ANSI

Flange DN	PN	15 (5N) 1/2"	20 (7N) 3/4"	25 (10N) 1"	32 (12N) 1 1/4"	40 (15N) 1 1/2"	50 (20N) 2"	Test pressure (*) PT
ANSI								
10- MRS Ro We..	16	X	X	X	X	X	X	PN 16
10- MRS Ro St..	16	X	X	X	X	X	X	PN 16
10- MRS Ro Pn..	16	X	X	X	X	X	X	PN 16

Flange connection measures DN65 – DN200 acc. to DIN EN 1092-2 / ANSI

Flange DN	PN	65 (25N) 2 1/2"	80 (30N) 3"	100 4"	125 5"	150 6"	200 8"	Test pressure (*) PT
ANSI								
10- MRS Ro We..	16	X	X	X	X	X	X	PN 16
10- MRS Ro St..	16	X	X	X	X	X	X	PN 16
10- MRS Ro Pn..	16	X	X	X	X	X	X	PN 16

(*) Test pressure to perform leakage test "No FUNCTION TEST"

X Type examination EU/2016/426, CE-0085AQ0616, O Acceptance test certificate 3.2 possible, - not available,

1.2 Application

The flow-control-slide-valves MRS are used for regulating and throttling the volumetric flow in the entire firing technology.

The flow-control-butterfly-valve are suitable for gases of the 1st, 2nd and 3rd gas families to DIN EN 437 and for neutral gases and air. There also is a version made of materials suitable for aggressive gases, and as an alternative for fluid media.

If used in other cases, the operator must carefully check if construction/design of flow-control-slide-valve, accessories and materials are suitable for the new application. The range of application is subject to the responsibility of the plant planner. The service life of the flow-control-slide-valve is 20 years.

2.0 Danger Notices

2.1 Safety terms

The signal terms DANGER, CAUTION und NOTICE are used in this operating manual in case of notices concerning special dangers, or for unusual information requiring a special marking.



DANGER! means that in case of non-observance there is danger to life and/or considerable damage.



CAUTION! means that in case of non-observance there is danger of injury and/or damage.



NOTICE! means that attention is drawn to technical correlations/connections.

Observance of other, not especially marked notices concerning transport, assembly, operation and maintenance and other data (in the operating manual, product documentation and at the unit itself) is also essential, in order to avoid disturbances that might affect direct or indirect damage to property or injury to persons.

2.2 Safety notice

Non observance of safety instructions can lead to loss of any claim for damages.

Non observance can lead to the following mentioned dangers:

- Failure of important functions of the flow-control-slide-valve and plant
- Endangering of persons by electrical or mechanical influences.
- Protection against accidental contact for moving parts may not be removed as long as the flow-control-slide-valve is in operation.
- Leakage of dangerous media (e.g. explosive, toxic, hot) must be removed in the way that there is no danger for persons or environment. Laws and regulations must be observed.

2.3 Qualified staff

These are persons who are familiar with erection, assembly, starting, operation and maintenance of the product and who have special qualifications acc. to their activities and functions, e.g.:

- Instruction and obligation to carry out and meet all regional and in-house orders and requirements.
- Education or instruction according to the safety engineering standards in use and maintenance of adequate safety and working protection equipment.
- Training in first aid.

2.4 Unauthorized modification and spare part production

Modification or changes of the flow-control-slide-valve are only allowed after agreement of the manufacturer. Original drawings and accessories authorized by the manufacturer are for safety purposes. The use of other parts or unauthorized changes at the flow-control-slide-valve by third persons may cancel and abolish the manufacturer's liability for resulting consequences.

2.5 Unauthorized operation

Operational reliability of the delivered flow-control-slide-valve is only guaranteed in case of determined use in accordance to paragraph 1 of the operating manual. **The application limits mentioned on the type sign may on no account be exceeded.**

2.6 Safety information for the use in explosion-prone areas guideline 2014/34/EU

- The temperature of the medium must not exceed the respective temperature class, and respectively, the respective maximum permitted medium temperature as per operation guidelines.
- If the valve is heated (e.g. heating jacket), care must be taken, that the specified temperature class is kept in the line.
- The valve must be connected to the ground.
In the case most simple this can be realized via pipe screws by means of tooth discs.
Otherwise the connection to the ground must be implemented by other measures e.g. cable links.
- Control valves, electrical and electrical/mechanical drives as well as sensors must undergo a separate conformity check as per ATEX. In doing so the respective safety and explosion protection information in the operation instructions are to taken into special consideration.
- Any modifications whatsoever to the valve are not allowed. The ATEX approval is void with immediate effect if the valve is modified without prior authorisation (even including painting).
- UNI-Geräte GmbH must be consulted before any modifications are made.

Furthermore we point out the Guideline 1999/92/EG, which include the minimum regulations for the improvement of the health-related situation and the safety of the employees, who might be jeopardized by an explosive atmosphere.

2.7 Safety information regarding guideline 2014/68/EU attachment I



Danger!

UNI valves are not an accessory with a safety function as defined in the PED 2014/68 / EU Article 2 (4) and Article 4 (1) (d) by category IV
Use or classify!

3.0 Handling

3.1 Transport

For any transport works, the generally recognised technical rules and standards as well as rules for prevention of accidents must be observed.

During transport, storage and decommissioning, protective caps must be attached to the sides of the valve.

The goods to be transported must be carefully treated. During transport, the valve must be protected against strokes, impacts or vibration. The coat of lacquer may not be damaged. Transport temperature is -20°C up to $+60^{\circ}\text{C}$.

Never transport the flow-control-slide-valve on cable glands, equipment plugs or attachments.
Transport the flow-control-slide-valve on the flange bores or with a belt underneath the actuating drive.
(See illustration).



Transport the flow-control-slide-valves in a case or on a pallet with smooth base and put it softly on plain floor.

The goods must be checked on completeness and transport damage. See also section 9.0

3.2 Storage

If the flow-control-slide-valve is not installed immediately after delivery, it must be stored properly.

- Storage temperature -20°C up to $+60^{\circ}\text{C}$, dry and clean.
- The lacquering protects against corrosion in neutral dry atmosphere. Do not damage colour.
- In humid rooms, a drying agent or a heating resp. is necessary because of condensation of water.

Requirements according to DIN 7716 (products made of caoutchouc and rubber) must be met.

3.3 Handling before mounting

- Protect against atmospheric influences such as humidity.
- Appropriate treatment protects against damage.

4.0 Product Description

The flow-control-slide-valves in the MRS series are control valves as actuators for controlling without zero closure with a linear control characteristic (rangeability 20:1).

The valves have a leakage of 0.03% of the K_v value.


The minimal main volume is 20% of the K_v value.

Sectional drawing 11.1 Fig. 1, 2 and 3 shows the valve construction.

4.1 Function


The flow-control-slide-valve works according to the ball cock principle. Control and throttling of the medium is achieved manually via the volume control spindle (245) (setting 0° - 90°) or by an electrical or pneumatic actuator.

The flow-control-slide-valve can be set to a defined main volume (flow rate 20% - 100%), see section 4.1.1



4.1.1 Setting the main volume

The main volume is set manually.



1. Slacken and remove the protective cap (505).
2. Undo the hexagon lock nut (901).
3. By turning the cap nut (927) clockwise as far as the stop the main volume is reduced to 0%.
4. The characteristic of the flow rate can be gathered from the table below.
5. Turn the cap nut (927) counter-clockwise to adjust by the number of turns (dependent on type and main volume %)
6. Tighten the hexagon lock nut (901)
7. Screw on and tighten the protective cap (505)

4.1.2 Table for main volume

Type		Main volume in %				
		20%	40%	60%	80%	100%
..-MRS 5N (DN 15)	Turns	1	2	3	4	5
..-MRS 7N (DN 20)	Turns	1	2	3	4	5
..-MRS 10N (DN 25)	Turns	2,5	5	7,5	10	12,5
..-MRS 12N (DN 32)	Turns	3	6	9	12	15
..-MRS 15N (DN 40)	Turns	3,5	7	10,5	14	17,5
..-MRS 20N (DN 50)	Turns	5	10	15	20	25
..-MRS 25N (DN 65)	Turns	6	12	18	24	30
..-MRS 30N (DN 80)	Turns	7	14	21	28	34
..-MRS 100 (DN 100)	Turns	8	16	24	32	40
..-MRS 125 (DN 125)	Turns	10	20	30	40	50
..-MRS 150 (DN 150)	Turns	12	24	36	48	60
..-MRS 200 (DN 200)	Turns	9	18	27	36	45

4.2 Technical data

4.2.1 Electrical actuator (St)



Actuator incl. Console

Type	Torque Nm	Actuating time*				Voltage*			Positioner	
		30(25) s/90°	50(42) s/90°	60(50) s/90°	65 s/90°	230 VAC	115 VAC	24 VDC	ESR..	PMR..
NK 6010	10	-	X	X	-	X	X	-	-NK	-NK
NK 6015	15	-	X	X	-	X	X	-	-NK	-NK
NK DC3010	10	X	-	-	-	-	-	X	-NK	-
NL 3020	20	X	-	-	-	X	X	-	-NL	2-LC
NL 6020	20	-	-	X	-	X	X	-	-NL	2-LC
NL 3040	40	X	-	-	-	X	X	-	-NL	2-LC
NL 6040	40	-	-	X	-	X	X	-	-NL	2-LC
N 1	15	-	-	X	-	X	X	X	-N	PMR 3
N1 DC	16					-	-	X	-N	-
N 2A	21	X	-	X	-	X	X	X		PMR 3
N 3	35	X	-	X	-	X	X	X		PMR 3
N 4A	60	-	-	X	-	X	X	X		PMR 3
N 5A	80	X	X	-	-	X	X	X		PMR 3
N 5	110	X	X	-	-	X	X	X		PMR 3
NE 1	15	-	-	-	X	X	X	X		PMR #
NE 2	60	-	-	-	X	X	X	X		PMR #

* Other actuating times and voltages upon request

External mounting

4.2.1 Pneumatic rotary actuator (Pn)



Rotary actuator, single-acting incl. console

Type	PGF07	PGF10	PGF15	PGF20	PGF25	PGF30	PGF33	PGF 35
Torque Nm	6	10	22	30	60	90	160	210
Control pressure	5 – 10bar							

Max. valve loading by pipe power

The indicated moments may not work longer than 10s.

DN		8	10	15	20	25	32	40	50	65	80	100	125	≥150
Torsion	Nm	80	35	50	86	125	160	200	250 ¹⁾	325 ¹⁾	400 ¹⁾	-	-	-
Bending	Nm	35	70	105	225	340	475	610	1100	1600	2400	5000	6000	7600

¹⁾ Not valid in case of valves with flanges

Starting torque, pipe screws greased

DN		8	10	15	20	25	32	40	50	65	80	100	125	≥150
Torque	Nm	20	30	30	30	30	50	50	50	50	50	80	160	160

Starting torque, product screws and nuts greased

Screw		M6	M8	M10	M12	M16	M20	M24
Torque	Nm	5	11	22	39	70	110	150

4.3 Marking


The type sign on the solenoid drive has the following information:

- Fabricator
- Valve type, nominal width, pressure and temperature indication, fitting position
- Year of construction/ production no.
- Valve class and valve group acc.
- CE-sign and no. of relevant location
- Fluid group and test pressure PT

Refer also to section 10.0.

4.4 Selection of electric actuators and pneumatic rotary actuators

In operation, the maximum permissible differential pressure ($p_e - p_a$) must not be exceeded. The limits can be obtained from the diagram.



Example:		Solution:
Input pressure	$p_e = 7 \text{ bar}$	Pressure difference $7 \text{ bar} - 4 \text{ bar} = 3 \text{ bar}$
Output pressure	$p_a = 4 \text{ bar}$	Torque $= 15 \text{ Nm}$
Nominal width	DN 65	

Selected electric actuator NK6015 or higher
Selected pneumatic rotary actuator PGF 15 or higher

5.0 Installation

5.1 Warning of dangers during installation, operation and maintenance



DANGER!

Safe operation of the flow-control-slide-valve can only be guaranteed if it is installed, commissioned and maintained by qualified personnel (see point 2.3 “Qualified staff”) correctly and in observance of the warnings in this operating manual. Apart from that, the operation safety order and the qualified use of tools and protection equipment must be guaranteed. The operating instructions for the flow-control-slide-valve must be observed during all work on or with the flow-control-slide-valve. Failure to observe these instructions may result in injury or in damage to the flow-control-slide-valve or other installations.

5.2 Installation

Apart from the general installation guidelines, the following points should be observed:



NOTICE!

- The fitting position for flow-control-slide-valves (We) is arbitrary.
- The fitting position for flow-control-slide-valves (St/Pn) are vertical or horizontal drive.
- The inside of the valve and the pipeline must be free from foreign particles.
- Centre gaskets between the flanges.
- The connecting flanges must be aligned.
- Ensure that none of the components is strained during installation.
- The flow-control-slide-valve must not be used as a fixed point; it is supported by the pipework system.
- Protect flow-control-slide-valve from soiling, particularly during construction work.
- Thermal expansion of the pipework must be equalized using compensators.

6.0 Operation



DANGER!

Before commissioning a new installation or before starting up an installation again after repairs or modifications, ensure:

- The proper completion of all installation and assembly work!
- Commissioning only by “qualified staff” (see point 2.3).
- Installation or repair of existing guards and protection equipment.

6.1 Commissioning

- Before commissioning, check the data on material, pressure, temperature and flow direction with the layout plan of the pipework system.
- Depending on the field of application, the local regulations have to be observed, e.g. the operation safety order.
- Leakage inspection of the installed flow-control-slide-valve.

6.2 Shutting down

- Depending on the field of application, the local regulations have to be observed, e.g. the operation safety order.

6.3 Maintenance

Flow-control-slide-valves have to be checked at regular intervals for proper function and internal leak tightness. The intervals for regular inspections have to be defined by the operator according to the operating conditions. UNI-Geräte recommends an internal visual inspection once a year.

6.4 Putting back into operation

When putting a flow-control-slide-valves back into operation, ensure that all the necessary steps described in section 5.2 (Installation) and section 6.1 (Commissioning) are repeated.

Repair or maintenance works at the manufacturing company (UNI- Geräte)



DANGER!

Valves and fittings must be delivered clean and free from substances which are harmful to health or to the environment.

7.0 Troubleshooting

7.1 Detection of defects



DANGER!

Be sure to observe the safety instructions during troubleshooting.

If the malfunctions cannot be remedied using the following **“Troubleshooting plan (7.2)”** please contact the manufacturer.

In the event of faults in the function or operating behaviour of the valve, check whether the installation work was carried out and completed as described in this operating manual.

Depending on the field of application, the operation safety order must be observed.

Check the data on material, pressure, temperature, voltage and flow direction with the layout plan of the pipework system. In addition, check whether the operating conditions correspond to the technical data in the data sheet or on the rating plate.

7.2 Troubleshooting plan

Malfunction	Possible causes	Remedy
MRS Ro We		
no flow, or respectively low flow	The main volume is turned to 0%	Set main volume according to section 4.1.2
	Blockage in the pipeline system Foreign body in the pipeline	Check the pipeline Clean the pipeline
	Operating pressure too high	Compare the operating pressure against the data on the type plate
	Flange covers were not removed	Remove the flange covers
No outer seal-tightness	Seals are damaged	See section 8, Replacing the sealing elements (spare parts kit)
Opening and closing operation	Flow-control-slide-valve opens and closes sluggishly	See section 8, Replacing the grooved ball bearing (spare parts kit)
MRS Ro St (additionally)		
no flow, or respectively low flow	Actuator does not open or close	Switch on actuator, check voltage
	Positioner is not working	Check positioner voltage, replace
	Incorrect programming	Use manufacturer's original documentation
	Poor limit switch adjustment	Check the adjustment
MRS Ro Pn (additionally)		
Opening and closing operation	Rotary actuator does not open or close	Switch on control valve for rotary actuator
	Control valve is not working	Check voltage, replace
	Positioner is not working	Check the pressure connection, check connection to rotary actuator, replace
	Incorrect programming	Use manufacturer's original documentation



NOTICE!

Observe section 9.0 before all installation and repair work!

Observe section 6.4 when putting the valve back into operation!

8.0 Replace the flow-control-slide-valve

In addition to the general installation guidelines and the operation safety order, the following points must also be observed:



DANGER!

- Depressurised pipework system
- Cooled medium
- Emptied installation
- Vent pipework systems containing corrosive, inflammable, aggressive or toxic media
- Have dismantling work carried out only by qualified staff (see point 2.3)

8.1 Replacing the wearing parts

Take the flow-control-slide-valve (MRS Ro St) (MRS Ro Pn) out of service as described in section 6.2.

The spare parts kit is to be used if there is any damage to the sealing elements or the grooved ball bearing.

Fig.1 ..-MRS Ro We... DN15 – DN100

Slacken the cylinder head screws (910/2 with DN15 – DN50) or hexagon screws (900/2 with DN65 – DN80) with lock washers (905) and remove them from the valve chamber (100).

Take down the housing flange (108/2) from the sealing piece (226/2).

Take out the entire inner part (226/2, 237, 238, 255, 244, 212/1, 212/2, 302/2, 403/2, 403/3, 404/2, 405, 505, 901/1, 901/2, 943/2) from the valve chamber (100).

Unscrew the protective cap (505) of the spindle guide (212/2).

Slacken the hexagon nut (901/2). By turning the hexagon nut (901/1) clockwise, the volume adjusting cylinder (237) with guard (238) can be screwed downward by the volume adjusting spindle (244).

Unscrew spindle guide (212/2) from spindle guide (212/1) and remove with the volume adjusting spindle (244).



NOTE!

The disk MRS (240/2) and grooved ball bearing (302/2) between guide piece (255) and sealing piece (226/2) may fall out.

Unscrew the spindle guide (212/1) from the sealing piece (226/2).



CAUTION!

Knock out the dowel pin (943/1) and cleanly deburr the bore.

Reason: Burr in the bore of the volume control spindle (245) could ruin the lip ring (404/1) when assembling and therefore external seal-tightness can no longer be guaranteed.

Slacken the cylinder head screws (910/1 with DN15 – DN50) or hexagon screws (900/1 with DN65 – DN80) with lock washers (905) and remove them from the valve chamber (100).

Take down the housing flange (108/1) from the sealing piece (226/1).

Take out the entire inner part (226/1, 239, 240/1, 245, 302/1, 403/1, 404/1, 940, 966, 973) from the valve chamber (100).

Detach the sealing piece (226/1) from the control cylinder (239) with the volume control spindle (245).



NOTES!

The disk MRS (240/1) and grooved ball bearing (302/2) may fall out.

The lip ring (404/1) contained in the sealing piece (226/1), the o-ring (403/1) and the grooved ball bearing (302/1) must be replaced during the overhaul.



NOTE!

The renewable parts in the spare parts kit must be fitted when overhauling

Fig.2 ..-MRS Ro We... DN125 – DN150



CAUTION!

Knock out the dowel pin (943/1) and cleanly deburr the bore.

Reason: Burr in the bore of the volume control spindle (245) could ruin the lip ring (404/1) when dismantling/assembling and therefore external seal-tightness can no longer be guaranteed.

Unscrew and remove the spindle guide (212/2) from the sealing piece (226/1).

Slacken the hexagon screws (900/1 with DN100) or cylinder head screws (910/1 with DN125 – DN150) with lock washers (905) and remove them from the valve chamber (100).

Take down the housing flange (108/1) from the sealing piece (226/1). Remove the sealing piece (226/1) from the valve chamber (100) and lay it on a clean surface.



NOTE!

The disk MRS (240/1) and grooved ball bearing (302/1) between the control cylinder (239) and the sealing piece (226/1) may fall out.

Unscrew the protective cap (505) of the spindle guide (212/2).

Slacken the hexagon nut (901/2).

By turning the hexagon nut (901/1) clockwise, the volume adjusting cylinder (237) with guard (238) moves from the volume adjusting spindle (244) and thereafter the volume control spindle (245) with the control cylinder (239) move upwards out of the valve chamber (100).



CAUTION!

Risk of injury!

The volume adjusting cylinder (237) with guard (238) is loose in the control cylinder (239).

Withdraw the volume control spindle (245) with the control cylinder (239) and the inlying volume adjusting cylinder (237) with guard (238) upwards out of the valve chamber (100) and lay on a clean surface.

Slacken the hexagon screws (900/2 with DN100) or cylinder head screws (910/2 with DN125 – DN150) with lock washers (905) and remove them from the valve chamber (100).

Take down the housing flange (108/2) from the sealing piece (226/2). Remove the sealing piece (226/2) from the valve chamber (100).

Unscrew the spindle guide (212/1) from the sealing piece (226/2).

Remove the guide piece (255) with grooved ball bearing (302/2) and disk MRS (240/2) from the sealing piece (226/2).



NOTE!

Knock out the dowel pin (943/2) from the hexagon nut (901/1). Unscrew and remove the hexagon nut (901/1 and 901/2) from the volume adjusting spindle (244).

Pull out and remove the volume adjusting spindle (244) from the spindle guide (212/1).

Fig.3 ..-MRS Ro We... DN200



CAUTION!

Knock out the dowel pin (943/1) and cleanly deburr the bore.

Reason: Burr in the bore of the volume control spindle (245) could ruin the lip ring (404/1) when dismantling/assembling and therefore external seal-tightness can no longer be guaranteed.

Undo the hexagon nuts (901/4) and remove along with the lock washers (905). Remove the hexagon screws (900/1) from the valve chamber (100).

Detach the sealing piece (226/1) from the valve chamber (100).

Unscrew the protective cap (505) of the spindle guide (212/1).

Slacken the hexagon nut (901/2).

By turning the hexagon nut (901/1) clockwise, the volume adjusting cylinder (237) with adjusting spring (997) moves from the volume adjusting spindle (244) and thereafter the volume control spindle (245) with the control cylinder (239) move upwards out of the valve chamber (100).



CAUTION!
Risk of injury!

The volume control cylinder (237) with adjusting spring (997) is loose in the control cylinder (239).

Withdraw the volume control spindle (245) with the control cylinder (239) and the inlying volume adjusting cylinder (237) with adjusting spring (997) upwards out of the valve chamber (100) and lay on a clean surface.

Undo the hexagon nuts (901/3) and remove along with the lock washers (905). Remove the hexagon screws (900/2) from the valve chamber (100).

Take out the entire inner part (108/1, 212/1, 212/2, 244, 302/2, 403/2, 404/2, 901/1, 901/2) from the valve chamber (100).

Take down the guide piece (255) with grooved ball bearing (302/2) from the spindle guide (212/2).



NOTE!

Knock out the dowel pin (943/2) from the hexagon nut (901/1). Unscrew and remove the hexagon nut (901/1 and 901/2) from the volume adjusting spindle (244).

Undo the setscrew (941). Unscrew the spindle guide (212/1) from the spindle guide (212/2).

Pull out and remove the volume adjusting spindle (244) from the spindle guide (212/2).

Unscrew and remove the spindle guide (212/2) from the housing flange (108/1).



NOTE!

The renewable parts in the spare parts kit must be fitted when overhauling.

Assemble the flow-control-slide-valve in the reverse order to disassembling.



CAUTION!

Install the wearing parts properly and do not damage them when assembling.

Examine the valve acc. to DIN EN 12266-1 for internal and external leaks and finally carry out a function test.

9.0 Warranty

Scope and period of the warranty is specified in the edition of the "General Terms of Business of the UNI-Geräte E. Mangelmann Elektrotechnische Fabrik GmbH" valid at the time of delivery or else in the purchase agreement.

We warranty that the valve is free from faults in line with the state of the art and for the confirmed field of application.

No warranty claims will be accepted for damage resulting from improper use or failure to observe these operating and installation instructions, the statutory accident prevention regulations, the EN, DIN and VDE standards and other codes and regulations.

Warranty claims will also not be accepted for damage occurring during operation due to operating conditions deviating from those specified in the data sheet or in other agreements.

Justified complaints will be remedied by reworking by us or specialist companies authorised by us. Claims going beyond the scope of the warranty will not be accepted. The customer shall have no right to the supply of a replacement valve.

Maintenance work, installation of parts from other manufacturers, any modifications to the design and natural wear are not covered by the warranty.

Transport damage must be reported not to us but **without delay** to your responsible goods handling company, the railway company or the shipping agent as otherwise all claims for damages against these companies will be voided.

10.0 Explanations on Codes and Directives

The Commission of the European Union has laid down common directives resp. regulations for the free trading of goods within the Union specifying minimum requirements for safety and health protection. The CE symbol confirms that products comply with the EU directives resp. regulations, i.e. in conformity with the relevant, in particular harmonised standards. Regulation EU/2016/426 and directive 2014/68/EU are of relevance for the flow-control-slide-valve (mechanical part).

Notes on Regulation EU/2016/426 (Gas Appliances Regulation GAR):

The flow-control-slide-valve have been developed, manufactured and tested in compliance with the applicable harmonised standard and comply with the relevant requirements of the Regulation EU/2016/426. Unless otherwise stated separately, this has been confirmed by a type examination.

Notes on Directive 2014/68/EU (Pressure Equipment Directive, DGRL):


It has been conformed that the quality assurance in design control, manufacture and final acceptance of the manufacturer, UNI-Geräte E. Mangelmann Elektrotechnische Fabrik GmbH, satisfy the requirements of 2014/68/EU Article 14 Module H. The flow-control-slide-valve comply with the fundamental requirements of Directive 2014/68/EU. Valves in according to Article 1 Paragraph 2,f,v or Article 4 paragraph 3 are not allowed to have the CE Mark in according to Article 18.


Note concerning ex-guideline 2014/34/EU (explosion guideline ATEX):

The product is not subject to guideline 2014/34/EU, since due to the loads occurring during practical operation, there is no effective source of ignition even in case of an error case to be assumed. This also applies to spring loaded components in medium filled rooms. In case of electric drives, sensors or other electric components the application as per 2014/34/EU is to be checked separately.

11.0 Drawing


11.1 Fig.1 Sectional drawing DN 15 – DN 100



 = Spare part kit


403/3* not applicable for DN 15 – DN 25


Fig.2 Sectional drawing DN 125 – DN150



○ = Spare part kit


Fig.3 Sectional drawing DN 200




 = Spare part kit

11.2 View drawing


11.2.1 View drawing ...MRS Ro We... DN 15 – DN 50




11.2.2 View drawing ...MRS Ro We... DN 65 – DN 100




11.2.3 View drawing ...MRS Ro We... DN 125 – DN 150




11.2.4 View drawing ...MRS Ro We... DN 200




11.2.5 View drawing ...MRS Ro St...




11.2.6 View drawing ...MRS Ro St (series NE)



11.2.7 View drawing ...MRS Ro Pn...



11.2.8 View drawing MRS Ro Pn.. /positioner



11.3 List of parts

Pos./ Item	St. / Qty.	Benennung	Description
100	1	Ventilgehäuse	valve chamber
108/1	1	Gehäuseflansch	housing flange
108/2	1	Gehäuseflansch	housing flange
212/1	1	Spindelführung	spindle guide
212/2	1	Spindelführung	spindle guide
212/3	1	Spindelführung	Spindle guide
226/1	1	Dichtstück	sealing piece
226/2	1	Dichtstück	sealing piece

Pos./ Item	St. / Qty.	Benennung	Description
237	1	Mengeneinstellzylinder	volume adjusting cylinder
238	1	Kulisse	guard
239	1	Regelzylinder	control cylinder
240/1	1	Scheibe (MRS)	disk (MRS)
240/2	1	Scheibe (MRS)	disk (MRS)
244	1	Mengeneinstellspindel	volume adjusting spindle
245	1	Mengenregelspindel	volume control spindle
255	1	Führungsteil	guide piece
302/1	1	Rillenkugellager	deep groove ball bearing
302/2	1	Rillenkugellager	deep groove ball bearing
403/1	1/2	O-Ring	o-ring
403/2	1	O-Ring	o-ring
403/3	1	O-Ring	o-ring
403/4	1	O-Ring	o-ring
404/1	2	Lippenring	lip-ring
404/2	2	Lippenring	lip-ring
405	1	Abstreifring	Scraper ring
505	1	Schutzkappe	protective cap
900/1	8/12	Sechskantschraube	hex. head screw
900/2	8/12	Sechskantschraube	hex. head screw
901/1	1	Sechskantmutter	hex. nut
901/2	1	Sechskantmutter	hex. nut
901/3	12	Sechskantmutter	hex. nut
901/4	12	Sechskantmutter	hex. nut
905	4/8/12/24	Federring	lock washer
907	2	Senkschraube	countersunk bolt
910	2	Zylinderschraube	cylinder head screw
910/1	4/8	Zylinderschraube	cylinder head screw
910/2	4/8	Zylinderschraube	cylinder head screw
940	3	Halbrundniete	semi-round rivetting
941	1	Gewindestift	setscrew
943/1	1	Spannstift	spring dowel sleeve
943/2	1	Spannstift	spring dowel sleeve
943/3	4	Spannstift	spring dowel sleeve
966/1	1	DU-Buchse	DU liner
966/2	1	DU-Buchse	DU liner
973	1	Skala	scale
997	1	Passfeder	adjusting spring

11.4 Dimension MRS Ro We....

Flange DN	Dimension	15 (5N)	20 (7N)	25 (10N)	32 (12N)	40 (15N)	50 (20N)	65 (25N)	80 (30N)	100	125	150	200
Installation length	A	130	150	160	180	200	230	290	310	350	400	480	608
	B	156	156	160	170	177	184	238	251	267	319	358	335
10-MRS...(N)-4	B`	206	208	210	220	227	234	288	301	317	369	433	435
	C	153	158	161	160	182	191	206	213	207	240	251	508
	D	84	86	82	82	86	85	88	86	84	77	82	139
	E	71	73	68	68	73	71	74	72	69	72	68	102
	ØF	15	15	20	20	20	20	20	20	20	20	20	30
	ØF`	15	15	15	15	15	15	15	15	15	15	15	-
	G	24	24	32	32	45	45	45	45	45	45	45	60
	H	38	38	46	55	70	70	70	70	70	70	70	150
	I	48	48	58	65	82	90	95	115	135	195	200	305
	K	M6	M6	M6	M8	M8	M8	M8	M8	M8	M8	M8	M10

A = Dimension at DIN (resp. flanges ANSI and dimension DIN or flanges and dimension at DIN)

B` = Dimension for removal of the protective cap

ØF` = Dimension for customer-specific volume control spindle

Dimension ..-MRS Ro St... (electrical actuator)

Flange DN	Dimension	15 (5N)	20 (7N)	25 (10N)	32 (12N)	40 (15N)	50 (20N)	65 (25N)	80 (30N)	100	125	150	200
Installation length	A	130	150	160	180	200	230	290	310	350	400	480	608
	MRS...(N)-4												
	B	156	156	160	170	177	184	238	251	267	319	358	335
	B`	206	208	210	220	227	234	288	301	317	369	433	435
with actuator of series NL (NL3020, NL3040, NL6020, NL6040)													
	C	199	202	209	209	226	236	248	257	253	293	299	499
	D	329	332	339	339	356	366	378	387	383	423	429	629
with positioner of series PMR 2-LC													
	D`	385	388	395	395	412	422	434	443	439	479	485	685
with actuator of series NK (NK6010, NK6015) with optional integrated positioner PMR-NK													
	C	204	207	214	214	231	241	253	262	258	298	304	504
	D/D`	328	331	338	338	355	365	377	386	382	422	428	628
with actuator of series N (N1, N2, N2A, N3, N4A, N5A, N5)													
	C	199	202	209	209	226	236	248	257	253	293	299	499
	D	329	332	339	339	356	366	378	387	383	423	429	629
with actuator of series N (N1, N2, N2A, N3, N4A, N5A, N5)													
	D`	385	388	395	395	412	422	434	443	439	479	485	685

B` = Dimension for removal of the protective cap

D` = Dimension with integrated positioner

Dimension ..-MRS Ro Pn... (pneumatic actuator)

Flange DN	Dimension	15 (5N)	20 (7N)	25 (10N)	32 (12N)	40 (15N)	50 (20N)	65 (25N)	80 (30N)	100	125	150	200
Installation length	A	130	150	160	180	200	230	290	310	350	400	480	608
	MRS...(N)-4												
	B	156	156	160	170	177	184	238	251	267	319	358	335
	B`	206	208	210	220	227	234	288	301	317	369	433	435
	C	199	202	209	209	226	236	248	257	253	293	299	499
with rotary actuator PGF 07													
	D	266	269	276	276	293	303	315	324	320	360	366	566
with rotary actuator PGF 10													
	D	294	297	304	304	324	331	343	352	348	388	394	594
with rotary actuator PGF 15													
	D	310	313	320	320	337	347	359	368	364	404	410	610
with rotary actuator PGF 20													
	D	332	335	342	342	359	369	381	390	386	426	432	632
with rotary actuator PGF 25													
	D	358	361	368	368	385	395	407	416	412	452	458	658
with rotary actuator PGF 30													
	D	373	376	383	383	400	410	422	431	427	467	473	673
with rotary actuator PGF 33													
	D	401	404	411	411	428	438	450	459	455	495	501	701
with rotary actuator PGF 35													
	D	416	419	426	426	443	453	465	474	470	510	516	716
with rotary actuator Sipart PS2 (6DR5010 / 6DR5020)													
	E	145	145	145	145	145	145	145	145	145	145	145	145